

..... (& ž (() ž UbX' ()) '
@Uk b'UbX'; UfXYb'HfUWcf'g''

-
-
-

..... TECHNICAL
..... MANUAL

-
-
-
-
-
-
-
-
-
-

.....>c\ b'8 YYfY'
..... K cf`Xk]XY7 ca a YfWU'UbX'
..... 7 cbgi a Yf'9ei]da Ybh8]j]g]cb''

..... TM1517 (Sep99)
..... Replaces TM1517 (15Sep96)

This technical manual is written for an experienced technician and contains sections that are specifically for this product. It is a part of a total product support program.

The manual is organized so that all the information on a particular system is kept together. The order of grouping is as follows:

- Table of Contents
- General Diagnostic Information
- Specifications
- Electrical Wiring Harness Legend
- Component Location
- System Schematic
- Wiring Harness
- Troubleshooting Chart
- Theory of Operation
- Diagnostics
- Tests and Adjustments
- Repair

Note: Depending on the particular section or system being covered, not all of the above groups may be used.

Each section will be identified with a symbol rather than a number. The groups and pages within a section will be consecutively numbered.

We appreciate your input on this manual. To help, there are postage paid post cards included at the back. If you find any errors or want to comment on the layout of the manual please fill out one of the cards and mail it back to us.

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1999
Deere & Co.
John Deere Worldwide Commercial and
Consumer Equipment Division
Horicon, WI
All rights reserved
Previous Editions
COPYRIGHT© 1996, 1995, 1994, 1992,
1991, 1990, 1989, and 1988

Safety



Specifications and Information



Engine



Diesel Engine



Electrical



Hydrostatic Power Train



Steering



Brakes



Hydraulics



Miscellaneous





RECOGNIZE SAFETY INFORMATION



This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe servicing practices.

Understand Signal Words

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.


REPLACE SAFETY SIGNS



Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.

HANDLE FLUIDS SAFELY—AVOID FIRES

Be Prepared for Emergencies



When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.


Do not store oily rags; they can ignite and burn spontaneously.

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

USE CARE IN HANDLING AND SERVICING BATTERIES



Prevent Battery Explosions


- Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.
- Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.
- Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).

Prevent Acid Burns

- Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.
- **Avoid acid burns by:**
 1. Filling batteries in a well-ventilated area.
 2. Wearing eye protection and rubber gloves.
 3. Avoiding breathing fumes when electrolyte is added.
 4. Avoiding spilling or dripping electrolyte.
 5. Using proper jump start procedure.
- **If you spill acid on yourself:**
 1. Flush your skin with water.
 2. Apply baking soda or lime to help neutralize the acid.
 3. Flush your eyes with water for 10—15 minutes.
 4. Get medical attention immediately.
- **If acid is swallowed:**
 1. Drink large amounts of water or milk.
 2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
 3. Get medical attention immediately.

USE CARE AROUND HIGH-PRESSURE FLUID LINES

Avoid High-Pressure Fluids



Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid injury from escaping fluid under pressure by stopping the engine and relieving pressure in the system before disconnecting or connecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.

Avoid Heating Near Pressurized Fluid Lines




Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



USE SAFE SERVICE PROCEDURES

Wear Protective Clothing




Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.

Service Machines Safely




Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.

Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards. Use power tools only to loosen threaded parts and fasteners. For loosening and tightening hardware, use the correct size tools. **DO NOT** use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches. Use only service parts meeting John Deere specifications.


Park Machine Safely



Before working on the machine:

1. Lower all equipment to the ground.
2. Stop the engine and remove the key.
3. Disconnect the battery ground strap.
4. Hang a "DO NOT OPERATE" tag in operator station.

Support Machine Properly and Use Proper Lifting Equipment



If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

Lifting heavy components incorrectly can cause severe injury or machine damage. Follow recommended procedure for removal and installation of components in the manual.

Work in Clean Area

Before starting a job:

1. Clean work area and machine.
2. Make sure you have all necessary tools to do your job.
3. Have the right parts on hand.
4. Read all instructions thoroughly; do not attempt shortcuts.


Using High—Pressure Washers

Directing pressurized water at electronic/electrical components or connectors, bearings, hydraulic seals, fuel injection pumps or other sensitive parts and components may cause product malfunctions. Reduce pressure and spray at a 45 to 90 degree angle.

Illuminate Work Area Safely

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.

Work in Ventilated Area



Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.

WARNING: California Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Gasoline engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust. Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch. Do all work outside or in a well ventilated area. Dispose of paint and solvent properly. Remove paint before welding or heating. If you sand or grind paint, avoid breathing the dust. Wear an approved respirator. If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Avoid Harmful Asbestos Dust

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos. Keep bystanders away from the area.



SERVICE TIRES SAFELY



Explosive separation of a tire and rim parts can cause serious injury or death.


Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job. Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



AVOID INJURY FROM ROTATING BLADES, AUGERS AND PTO SHAFTS



Keep hands and feet away while machine is running. Shut off power to service, lubricate, or remove mower blades, augers, or PTO shafts.


SERVICE COOLING SYSTEM SAFELY



Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off machine. Remove filler cap only when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

HANDLE CHEMICAL PRODUCTS SAFELY



Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques. Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

Dispose of Waste Properly

Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment includes such items as oil, fuel, coolant, brake fluid, filters, and batteries. Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them. Do not pour waste onto the ground, down a drain, or into any water source. Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.

LIVE WITH SAFETY



Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.

CONTENTS

SPECIFICATIONS AND INFORMATION

	Page
GENERAL VEHICLE SPECIFICATIONS	10
TORQUE VALUES, NON-STANDARD FASTENERS	10
GASOLINE ENGINE	10
DIESEL ENGINE	11
POWER TRAIN, HYDROSTATIC	12
STEERING	12
BRAKES	12
HYDRAULICS	12
METRIC FASTENER TORQUE VALUES	13
INCH FASTENER TORQUE VALUES	14
O-RING SEAL SERVICE RECOMMENDATIONS	15
FACE SEAL FITTINGS WITH INCH STUD ENDS TORQUE	15
FACE SEAL FITTINGS WITH METRIC STUD ENDS TORQUE	16
O-RING FACE SEAL FITTINGS	17
O-RING BOSS FITTINGS	17
STRAIGHT FITTING OR SPECIAL NUT TORQUES	18
METRIC FASTENER TORQUE VALUE—GRADE 7 (SPECIAL)	18
GASOLINE	19
4-CYCLE ENGINES	19
GASOLINE STORAGE	19
DIESEL FUEL	20
DIESEL FUEL LUBRICITY	20
DIESEL FUEL STORAGE	20
ENGINE OIL SPECIFICATIONS	21
4-CYCLE DIESEL ENGINE OIL	21
4-CYCLE GASOLINE ENGINE OIL	22
BREAK-IN ENGINE OIL—DIESEL	23
BREAK-IN ENGINE OIL—4-CYCLE GASOLINE	24
HYDROSTATIC TRANSMISSION AND HYDRAULIC OIL	25
HYDROSTATIC TRANSMISSION AND HYDRAULIC OIL	25
GEAR CASE OIL SPECIFICATIONS	26
GEAR CASE OIL	26
GEAR TRANSMISSION GREASE SPECIFICATIONS	27
GEAR TRANSMISSION GREASE	27
ALTERNATIVE LUBRICANTS	28
SYNTHETIC LUBRICANTS	28
LUBRICANT STORAGE	28
MIXING OF LUBRICANTS	28
OIL FILTERS	28
COOLANT SPECIFICATIONS	29
DIESEL AND GASOLINE ENGINE COOLANT	29
DIESEL AND GASOLINE ENGINE COOLANT DRAIN INTERVAL	29
SERIAL NUMBER LOCATIONS	30





	Page
PRODUCT SERIAL NUMBER	30
DIESEL ENGINE SERIAL NUMBER LOCATION	30
GASOLINE ENGINE SERIAL NUMBER LOCATION	30
TRANSAXLE SERIAL NUMBER LOCATION	30

GENERAL VEHICLE SPECIFICATIONS

TORQUE VALUES, NON-STANDARD FASTENERS

All torque specifications are subject to final verification.

NOTE: Torques listed in this GROUP apply ONLY to "special" and/or NON-STANDARD fasteners. Unless otherwise specified, STANDARD fasteners should be torqued per "TORQUE VALUES, STANDARD METRIC METRIC FASTENER" or "TORQUE VALUES, STANDARD INCH FASTENER".

GASOLINE ENGINE

Engine Mounting Cap Screws	80 N•m (60 lb-ft)
Valve Clearance Adjusting Nut	9 N•m (79 lb-in.)
Carburetor Mounting Nuts	17 N•m (12 lb-ft)
Intake Manifold Cap Screw (Final)	6 N•m (53 lb-in.)
Pressure Relief Plug	15 N•m (133 lb-in.)
Thermostat Housing Cap Screws	6 N•m (53 lb-in.)
Rocker Arm Adjuster Screw Lock Nut	9 N•m (79 lb-in.)
Cylinder Head Cap Screw (Final)	21 N•m (186 lb-in.)
Spark Plug	20 N•m (177 lb-in.)
Crankcase Cover Cap Screw	21 N•m (186 lb-in.)
Crankcase Drain Plug	23 N•m (204 lb-in.)
Connecting Rod Cap Screw	21 N•m (186 lb-in.)
Coolant Pump Cap Screw	8 N•m (70 lb-in.)
Crankcase Cover Cap Screw	23 N•m (17 lb-ft)
Oil Pump Cover Cap Screw	7.8 N•m (69 lb-in.)
Ignition Coil Cap Screws	9.8 N•m (87 lb-in.)
Starting Motor Mounting Cap Screw	15.3 N•m (135 lb-in.)
Governor Arm Nut	7.8 N•m (69 lb-in.)

Flywheel:

Flywheel Nut	108 N•m (80 lb-ft)
Flywheel Sheave	15 N•m (130 lb-ft)
Fan Belt Drive Sheave Screw	15 N•m (133 lb-in.)

Carburetor—425:

Throttle Shaft Retaining Screw	2 N•m (17 lb-in.)
Drain Screw	1.2 N•m (10 lb-in.)
Choke and Throttle Valve Screw	0.88 N•m (7.8 lb-in.)
Solenoid Valve Torque	9.8 N•m (87 lb-in.)
Main Jet and Main Air Jet Torque	1.0 N•m (8.9 lb-in.)
Air Horn Mounting Screws	2.9 N•m (26 lb-ft)

Throttle Body—445:

Throttle Shaft Retaining Screw	2.0 N•m (17 lb-ft)
Throttle Plate Screws	2.0 N•m (17 lb-ft)
Mounting Stud Nuts Torque	17 N•m (12 lb-ft)

DIESEL ENGINE

Muffler-to-Manifold Nuts	28 N•m (20 lb-in.)
Thermostat Housing Cap Screw	9 N•m (78 lb-in.)
Nozzle Torque	50 N•m (37 lb-ft)
Piston and Connecting Rod Cap Screw	23 N•m (97 lb-in.)
Seal Case-to-Block Cap Screw	11 N•m (96 lb-in.)
Oil Pan-to-Seal Case Cap Screw	9 N•m (78 lb-in.)
Crankshaft Main Bearing Cap Screw	54 N•m (40 lb-ft)
Camshaft Mounting Cap Screw.	11 N•m (96 lb-in.)
Intake Manifold Cap Screws	11 N•m (96 lb-in.)
Exhaust Manifold Cap Screw/Nut	11 N•m (96 lb-in.)
Rocker Arm Cover Special Screw	18 N•m (160 lb-in.)
Rocker Arm Assembly Mounting Cap Screw and Nut.	26 N•m (19 lb-ft)
Cylinder Head Cap Screws (Final)	34 N•m (25 lb-ft.)
Oil Pump Mounting Cap Screw	25 N•m (18 lb-ft)
Flywheel Cap Screws	83 N•m (61 lb-ft)
Flywheel Plate Mounting Cap Screw.	49 N•m (36 lb-ft)

Cooling System:

Coolant Pump Mounting Cap Screws	26 N•m (19 lb-ft)
Cooling Fan Mounting Cap Screw	11 N•m (96 lb-in.)
Coolant Pump Plate-to-Housing Screw.	9 N•m (78 lb-in.)

Fuel Injection:

Pump Mounting Nut	20 N•m (180 lb-in.)
Pump Camshaft Bearing Retaining Screw	20 N•m (180 lb-in.)
Mounting Nut	40 N•m (30 lb-ft)
Nozzle Fitting	40 N•m (30 lb-ft)

Oil Pan and Strainer:

Oil Pan-to-Block Mounting Cap Screw	11 N•m (96 lb-in.)
Oil Pan-to-Seal Case Mounting Cap Screw	9 N•m (78 lb-in.)
Oil Pan-to-Timing Gear Housing Mounting Cap Screw.	9 N•m (78 lb-in.)
Oil Strainer--to-Block Cap Screws Mounting Cap Screw	11 N•m (96 lb-in.)

Timing Gear Cover and Housing:

Fan Mounting Cap Screw	11 N•m (96 lb-in.)
Cover Mounting Cap Screw	9 N•m (78 lb-in.)
Crankshaft Pulley Cap Screw	115 N•m (85 lb-ft)
Aluminum Housing-to-Block	9 N•m (78 lb-in.)
Cast Iron Housing-to-Block.	11 N•m (96 lb-in.)

Alternators:

Flywheel Assembly-to-Coil Plate Assembly Nut (KoKosan 20A).	27 N•m (20 lb-ft)
Retainer-to-Front Frame Screw (Nippeondenso 40A).	2 N•m (16 lb-in.)
Sheave Nut (Nippeondenso 40A)	69 N•m (51 lb-ft)

POWER TRAIN, HYDROSTATIC

Control Arm Cap Screw	73 N•m (54 lb-ft)
Axle Housing Cap Screws Torque	54 N•m (40 lb-ft)
King Pin Cap Screws Torque	54 N•m (40 lb-ft)
Transaxle to Frame Mounting Cap Screws	88 N•m (65 lb-ft)
Differential Bolts	78—98 N•m (58—72 lb-ft)



PTO:

Solenoid Armature	22 N•m (195 lb-in.)
Solenoid Nut	4.9 N•m (43 lb-in.)
Output Shaft Retaining Cap Screws	27 N•m (20 lb-ft)
Shifter Shaft Cap Screw	25 N•m (18 lb-ft)
Ball Switches	34 N•m (25 lb-ft)

Charge Pump Cap Screws:

Short Cap Screws Torque	25 N•m (18 lb-ft)
Long Cap Screw Torque	39 N•m (29 lb-ft)

Hydrostatic Center Valve Block:

Directional Control Valves	35 N•m (26 lb-ft)
Bottom Suction Plug	50 N•m (37 lb-ft)
Implement Relief Valve Plug	25 N•m (18 lb-ft)
Mounting Cap Screws	39 N•m (29 lb-ft)

STEERING

Steering Wheel Nut	38 N•m (28 lb-ft)
Steering Valve End Cover Cap Screw	17 N•m (150 lb-in.)
Check Ball Plug	17 N•m (150 lb-in.)
Front Axle Pivot Cap Screw and Lock Nut	68 N•m (50 lb-ft)
Tie Rod Lock Nut	61 N•m (45 lb-ft)
Rear Steering Linkage Lock Nut	170 N•m (125 lb-ft)
Adjusting Nut Jam Nuts	68 N•m (50 lb-ft)
Rear Steering Side Pivots Pivot Lock Nut	108 N•m (80 lb-ft)
Mounting Cap Screw and Nut	84 N•m (62 lb-ft)
Rear Axle Pivot Bracket Cap Screws	91 N•m (67 lb-ft)
Pivot Nut	67—83 N•m (49—61 lb-ft)
Ball Joint Castellated Nut	45—57 N•m (33—42 lb-ft)

BRAKES

Transaxle Brake Cover Cap Screws Used Transaxle Case	25 N•m (18 lb-ft)
New Transaxle Case	30 N•m (22 lb-ft)
Brake Switch Striker	12 N•m (108 lb-in.)

HYDRAULICS

Return Spring Bonnet Retaining Screw	2.7—4 N•m (24—36 lb-in.)
Return Spring Caps Retaining Screw	2.7—4 N•m (24—36 lb-in.)
Detent Ball Retaining Screw	2.7—4 N•m (24—36 lb-in.)
Work Port Cap	34—40.7 N•m (25—30 lb-ft)
Lift Check Valves Cap Screw	20—27 N•m (15—20 lb-ft)

METRIC FASTENER TORQUE VALUES



Property Class and Head Markings	4.8		8.8		9.8		10.9		12.9	
Property Class and Nut Markings	5		10		10		10		12	

TS1163

SIZE	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft
M6	48	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	109
M16	100	73	125	92	190	140	240	175	275	200	350	225	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

DO NOT use these hand torque values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only and include a ±10% variance factor. Check tightness of fasteners periodically. DO NOT use air powered wrenches.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same grade. Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

When bolt and nut combination fasteners are used, torque values should be applied to the **NUT** instead of the bolt head.












Tighten toothed or serrated-type lock nuts to the full torque value.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated (yellow dichromate - Specification JDS117) without any lubrication.

Reference: JDS—G200.

INCH FASTENER TORQUE VALUES



SAE Grade and Head Markings	1 or 2 ^b No Marks 	5  5.1  5.2 	8  8.2 
	2 No Marks 	5  	8  

TS1162

SIZE	Grade 1		Grade 2 ^b		Grade 5, 5.1 or 5.2				Grade 8 or 8.2							
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	215	160	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	470	300	510	375	470	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these hand torque values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only and include a ±10% variance factor. Check tightness of fasteners periodically. DO NOT use air powered wrenches.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same grade. Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

When bolt and nut combination fasteners are used, torque values should be applied to the **NUT** instead of the bolt head.

Tighten toothed or serrated-type lock nuts to the full torque value.




^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated (yellow dichromate - Specification JDS117) without any lubrication.

^b "Grade 2" applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. "Grade 1" applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.

Reference: JDS—G200.

O-RING SEAL SERVICE RECOMMENDATIONS

FACE SEAL FITTINGS WITH INCH
STUD ENDS TORQUE



Nominal Tube O.D./Hose I.D.				Face Seal Tube/Hose End					O-ring Stud Ends		
Metric Tube O.D.	Inch Tube O.D.			Thread Size	Tube Nut/ Swivel Nut Torque		Bulkhead Locknut Torque		Thread Size	Straight Fitting or Locknut Torque	
	mm	Dash Size	in.		mm	in.	N•m	lb-ft		N•m	lb-ft
	-3	0.188	4.76						3/8-24	8	6
6	-4	0.250	6.35	9/16-18	16	12	12	9	7/16-20	12	9
8	-5	0.312	7.94						1/2-20	16	12
10	-6	0.375	9.52	11/16-16	24	18	24	18	9/16-18	24	18
12	-8	0.500	12.70	13/16-16	50	37	46	34	3/4-16	46	34
16	-10	0.625	15.88	1-14	69	51	62	46	7/8-14	62	46
	-12	0.750	19.05	1-3/16-12	102	75	102	75	1-1/16-12	102	75
22	-14	0.875	22.22	1-3/16-12	102	75	102	75	1-3/16-12	122	90
25	-16	1.000	25.40	1-7/16-12	142	105	142	105	1-5/16-12	142	105
32	-20	1.25	31.75	1-11/16-12	190	140	190	140	1-5/8-12	190	140
38	-24	1.50	38.10	2-12	217	160	217	160	1-7/8-12	217	160

NOTE: Torque tolerance is +15 / -20%.